

KR-103 Quick Stats:

- 400 GM2/GS compatible tones
- 9 drum sets, 1 SFX Set
- 64-note polyphony
- 88-key Compact Progressive Hammer-Action keyboard
- 170 preset music styles
- 180 Music Assistants
- 50 built-in songs
- 34 user programs
- 16-track recorder
- Reverb, Chorus, Rotary and 47 Multi-FX
- Built-in 3.5" floppy disk drive

Selecting Tones

Use the following procedure to select a tone:

1. Press a tone button (e.g. Piano, Organ, Guitar/Bass, etc.) in the TONE section (located to the right of the LCD screen).
2. Use the + and – to the right of the LCD screen to toggle through tones.
3. Stop on the tone you wish to use.

Refer to the Owner's Manual, pg. 10 for more information, see pgs. 3-4 of this Turbo Start for a complete tone list.

Selecting Music Styles

Use the following procedure to select a Music Style from internal memory:

1. Press a music style button (e.g. Pop/Rock, Ballad/Acoustic, Oldies/Country etc.) in the MUSIC STYLE section (located to the left of the screen.)
2. Use the + and – to the right of the LCD screen to locate a music style in that genre.
3. Press the START/STOP button (located to the left of the screen) to play the music style; press the START/STOP button to silence the music style..

Refer to the Owner's Manual, pg. 19 for more information. See pg. 5 of this Turbo Start for a complete list of music styles.

Selecting One Touch Programs

Use the following procedure to select automatic accompaniment settings:

1. Select a Music Style as described under "Selecting Music Styles."

2. Press the ARRANGER button (located below the tone buttons.)
3. Play a note on the lower half of the keyboard.
4. Press the START/STOP button (located to the left of the screen) to silence the arrangement.

Refer to the Owner's Manual, pg. 33 for more information.

Selecting Music Assistants

Use the following procedure to select a Music Assistant:

1. Press the MUSIC ASSISTANT button (located to the left of the screen.)
2. Use the + and – to the right of the LCD screen to locate a Music Assistant song.
3. Play a note on the lower half of the keyboard to begin.
4. Press the START/STOP button (located to the left of the screen) to silence the piano.

Refer to the Owner's Manual, pg. 15 for more information. See pg. 6 of this Turbo Start for a list of Music Assistant songs.

Playing a Song from Disk

Use the following procedure to play a song from disk:

1. Insert a SMF music disk into the drive.
2. Press the SONG button (located to the left of the LCD screen.)
3. Use the + and – to the right of the LCD screen to locate a song.
4. Press the PLAY button (the gray button located to the left of the disk drive) to play the song.
5. Press the STOP button to silence the piano.

Refer to the Owner's Manual, pg. 23 for more information.

Recording a Song

Use the following procedure to record a song:

1. Press the REC button in the RECORD/PLAYBACK section (located to the left of the disk drive.) Select a Music Style as described under "Selecting Music Styles."

Note: If USER SONG does not appear on the screen, then use the arrow buttons next to the screen to select USER SONG

2. Play a song
3. Press the STOP button when you are done.
4. Press the RESET button.
5. Press the PLAY button to hear the song.

Refer to the Owner's Manual, pg. 28 for more information, including how to record with accompaniment.

Saving a Recorded Song to Disk

Use the following procedure to save a recorded song to disk:

1. Record a song as described under “Recording a Song.”
2. Insert a formatted disk into the drive.
3. Press the DISK button (located to the left of the Record/Playback area.)
4. Press ENTER
5. Use the + and – to select the song’s destination on the disk.
6. Press ENTER
7. Use the + and – buttons to change the title of the song, using the arrow buttons to change the letter space.
8. Press ENTER

Refer to the Owner’s Manual, pg. 32 for more information.

Selecting User Programs

Use the following procedure to select User Programs:

1. Press the USER PROGRAM button (located to the right of the volume knob).

2. Use the arrow buttons (located to the right of the LCD screen) to scroll until “Read” appears on the screen.
3. Press ENTER
4. Use the + and – buttons to scroll locate the user programs. Press ENTER for the program you wish to use.

Refer to the Owner’s Manual, pg. 46 for more information. See pg. 6 of the Turbo Start for the list of User Programs.

Intializing—Restoring Factory Settings

Use the following procedure to clear the internal memory and reload the factory settings:

Caution: *All USER information will be lost. Be sure to back up any information you wish to keep.*

1. Press the FUNCTION button (located on the left side of the piano.)
2. Use the arrow buttons (located to the right of the LCD screen) to scroll until “Fctry Rst” appears on the screen.
3. Press the ENTER button.
4. Factory settings are restored when “Reset Complete” appears on the screen.

Refer to the Owner’s Manual, pg. 45 for more information.

Tone List

Piano	048 Santur2	093 Mt DstBs	141 AcidBass	187 SynStrn2
001 Piano 1w	Organ	094 OvdvrGt	142 ResoSHBs	188 SynStrn3
002 Ballad Piano	049 RockOrg1	095 Dist Gt	143 ClaviBss	189 Violin
003 Piano 2	050 PercOrg2	096 Power Gt	144 JnglBass	190 SlwViolin
004 Honky Tonk	051 CoolOrgn	097 Ac.Bass2	145 Hammer	191 Viola
005 Soft EP	052 R&BOrgan	098 FngrdBs2	146 Mod Bass	192 Cello
006 Pro EP 1	053 Organ 1	099 Pckd Bs2	147 BeefFMBs	193 Contrbss
007 '60s EP 2	054 FullOrg3	100 FrtlsBs2	148 RubbrBss	194 Timpani
008 EPLegend	055 PopOrg1	101 NylonV/S	149 SH 101Bs1	195 Orch Hit
009 EP Phase	056 JazzOrg3	102 NylongGt2	150 SH 101Bs2	196 6 th Hit
010 Clav.	057 DtndOr2	103 SteelGt2	151 AttckPls	197 Euro Hit
011 Vib. W	058 ChrchOr2	104 Stl+Body	152 Ukulele	198 Bass Hit
012 Marimb w	059 FrMusett	105 Nyln+Stl	153 Sitar	199 Yang Qin
013 Harpschr	060 HarmHand	106 Mandolin	154 Sitar 2	200 Fiddle
014 Piano 1	061 BandonFr	107 MellowGt	155 Banjo	
015 Piano 2w	062 TrmOrgan	108 PedalStl	156 Shmisen	Sax/Brass
016 Up.Piano	063 Dtnd Or1	109 CleanGt.	157 Tsugaru	201 AltoFolk
017 Piano3	064 FullOrg2	110 CleanGt2	158 Koto	202 BlwTenor
018 Piano3w	065 FullOrg4	111 CleanGt3	159 TiashoKT	203 SoprnSax
019 EG+EP 1	066 Pop Org2	112 MidTneGT		204 FluteVib
020 EG+EP 2	067 Pop Org3	113 ChorusGT	Strings/Voice	205 Oboe
021 E. Piano	068 RotryOrF	114 Funk Gt.	160 Strings2	206 ClarFolk
022 FM+SA EP	069 ChseOrgn	115 Funk Gt2	161 SlwStrn3	207 Trumpet
023 Pop EP	070 RockOrgn	116 Jazz Man	162 St.Choir	208 Trombone
024 HardEP2	071 RotryOrS	117 Gt Pinch	163 Humming	209 MtdTrump
025 MellowEP	072 RockOrg2	118 Dist.Gt2	164 Violin 2	210 FrnchHrns
026 E.Piano 2	073 Organ 2	119 Dazed Gt	165 Viola 2	211 Brass 1
027 Dtnd EP2	074 Organ 4	120 Fdbck Gt	166 Cello 2	212 Brass 2
028 St.FM EP	075 Organ 5	121 FdbckGt2	167 Harp	213 HyprAlto
029 HardFM EP	076 OrganBss	122 PowerGt2	168 ChrAahs2	214 TenrSax2
030 CpldHps	077 ChorsOr2	123 RockRhyt	169 MelloChr	215 BartnSax
031 Harpsi.w	078 ChrchOr1	124 RockRhy2	170 DoosVoic	216 AtkFlute
032 Harpsi.o	079 ChrchOr3	125 DstRtmGT	171 RDSynVox	217 Piccolo
033 CompClav	080 OrgnFlte	126 5 th Dist	172 AnaVoice	218 EnglHorn
034 PulsClav	081 TrmFlute	127 GtHrmncs	173 SynVoice	219 Bassoon
035 Celesta	082 PuffOrgn	128 GtFdbck	174 Strings	220 Recorder
036 Glcksnpl	083 Accordn	129 AcGtHrmx	175 VeloStrn	221 PanFlute
037 MusicBox	084 ItalFolk	130 AcsticBs	176 RDStrngs	222 Trumpet2
038 Vibraphn	085 MellHarm	131 FingrdBs	177 Orchestra	223 Trumpet3
039 HardVibe		132 PckdBass	178 ChoirStr	224 RamantTp
040 Marimba	Guitar/Bass	133 JazzBass	179 SlwStrng	225 FlgHorn
041 Barafon	086 NylStrGt	134 Frtls Bs	180 SlwStrn2	226 Tb Soft
042 Barafon2	087 StlStrGt	135 MrSmooth	181 LegtoStr	227 BrightTb
043 Xylphone	088 12-strGt	136 SlpBass1	182 WarmStr	228 VMutedTp
044 TublBell	089 JazzGibs	137 SlpBass2	183 Trem Str	229 FrHornSl
045 ChrchBil	090 JC E.Gt.	138 SynBass1	184 PzzxtStr	230 Fr.Horn2
046 BellHrp	091 OpenHrd1	139 SynBass2	185 OBStrngs	231 HornOrch
047 Santur	092 Muted Gt	140 SynBas101	186 SynStrn1	232 Tuba

Tone List Continued

233 Brass 1w	265 NatrLead	300 Prologue	335 StlDrms	370 WndChims
234 SynBrass	266 SeqncdSw	301 Rave	336 Woodblck	371 Scratch2
235 SynBrss2	267 SnCallpe	302 SynMallt	337 Castnets	372 Helicptr
236 SynBrss3	268 PurPanLd	303 SftCryst	338 Taiko	373 CarEngne
237 OctSnBrS	269 ChiffrLd	304 RndGlock	339 ConcrtdBD	374 Car-Stop
238 JmpBrass	270 Charang	305 LoudFloc	340 MeloTom1	375 Car-Pass
239 SoftBrss	271 QireLead	306 GlknChm	341 MeloTom2	376 CarCrash
240 BottlBlw	272 DistLead	307 ClrBells	342 SyntDrum	377 Siren
241 Whistle	273 Solo Vox	308 XmasBell	343 808 Tom	378 Train
242 Ocarina	274 5thSawWv	309 VbrBells	344 ElecPerc	379 Jetplane
243 Shakuhch	275 BigFives	310 DigiBell	345 Rev Cym	380 Starship
244 Bagpipe	276 Bss&Lead	311 ChriBell	346 GtFrtNoz	381 BurstNs
245 Shanai	277 Big&Raw	312 AirBells	347 GtCtNoiz	382 Appleause
Others/Drum/S	278 Fat&Prky	313 Atmspher	348 Str Slap	383 Laughing
FX	279 DlydLead	314 WarmAtms	349 BassSld	384 Screaming
246 Fantasia	280 Soft Pad	315 NylnHarp	350 PickScrp	385 Punch
247 Fantsia2	281 Sine Pad	316 Harpvox	351 BrtNoise	386 HeartBt
248 Crystal	282 Polysyn	317 HillwRels	352 FIKClick	387 Fotstps
249 Warm Pad	283 80sPlySyn	318 Nylon+EP	353 Seashor	388 Applaus2
250 SawWave	284 SpcVoice	319 AmbntPad	354 Rain	389 Gun Shot
251 STNDARD1	285 HeavenII	320 Brightns	355 Thunder	390 MachnGun
252 SFX	286 Itopia	321 Goblin	356 Wind	391 Laergun
253 Sqr Wave	287 BowdGlss	322 Goblinsn	357 Stream	392 Xplosion
254 CC Solo	288 MetalPad	323 50sSciFi	358 Bubble	393 STNDARD2
255 Square	289 Tine Pad	324 EchDrops	359 Bird	394 ROOM
256 MellowFM	290 PannrPad	325 EchoBell	360 Dog	395 Power
257 Shmmog	291 Halo Pad	326 Echo Pan	361 HrseGllp	396 TR-808
258 LMSquare	292 SweepPad	327 EchoPan2	362 Bird 2	397 DANCE
259 SineWave	293 PolarPad	328 BigPannr	363 Kitty	398 Jazz Kit
260 P5 SawLd	294 Converge	329 ResoPannr	364 Growl	399 BRUSH
261 Big Lead	295 CelstlPd	330 WtrPiano	365 Telphn 1	400 ORCHSTRA
262 Dr. Solo	296 Ice Rain	331 StarThme	366 Telphn 2	
263 Saw	297 Africnwd	332 Kalimba	367 DoorCrk	
264 WaspySYn	298 Sndtrack	333 TnklBell	368 Door	
	299 Ancestrl	334 Agogo	369 Scratch	

Internal Song List

001	Liebesträume 3	021	Radetzky Marsch	042	Gavotte
002	Etude, op.10-3	022	Träumerei	042	La Cinquantaine
003	Je te veux	023	Moments Musicaux 3	043	Csikos Post
004	Valse, op.64-1	024	Prelude, op.28-15	044	Fröhlicher Landmann
005	Golliwog's Cakewalk	025	Harmonious Blacksmith	045	Preludelight
006	Fantaisie Impromptu	026	Ungarische Tänze 5	046	Blue Sky Rag
007	Arabesque 1	027	Türkischer Marsch	047	Late Night Chopin
008	Blauen Donau	028	Nocturne No.2	048	Canon (Pachelbel)
009	Auf Flügeln des Gesanges	029	Frühlingslied	049	Ombra maifu
010	Mazurka No.5	030	Präludium	050	Secret Agent
011	Gymnopedie 1	031	Für Elise	051	Fly Free
012	Etude, op.25-1	032	Türkischer Marsch(Mozart)	052	Sun Daze
013	Clair de Lune	033	Ständchen	053	Keepers Tale
014	Etude, op.10-5	034	Humoreske	054	Count On The Blues
015	Dr.Gradus Ad Parnassum	035	Blumenlied	055	One Down And Easy
016	Grande Valse Brillante	036	Alpenglöckchen	056	A Prelude To ...
017	La prière d'une Vierge	037	Menuett G-dur (Beethoven)	057	Bach's A Boppin'
018	Course en Troïka	038	Venezianisches Gondellied	058	Kismet's Salsa
019	To The Spring	039	Brautchor	059	From Matthew's Passion
020	Valse, op.64-2	040	Le Coucou	060	Roll Over Ludwig
		041	Menuett G-Dur (Bach)		

Music Style List

<u>Pop/Rock</u>	035	ShuffleRk	069	VibeyPop	104	Country	137	PasDoble		
001	BigHouse	036	DynoRock	070	6/8Balld	105	Oldie6/8	138	Gospel	
002	EuroDnce	037	ThumpRck	071	Ballad	106	CntryBld	139	SoftGosp	
003	90sHouse	038	UpTownRk	072	USBallad	<u>Big Band/Swing</u>	140	GosplBld		
004	70sDisco	<u>Ballad/Acoustic</u>	039	EuroBlld	073	NghtBld	141	GosplPop		
005	70sDance	040	LoveBeat	074	6/8 Pop	108	BgBndMed	142	GspShout	
006	Twostep	041	BrghtPop	075	UnplBlld	109	BgBndFst	143	GospShfl	
007	FeverDnc	042	LightPop	076	CoolBand	110	SwingMed	144	TrdRhmba	
008	80sTeKno	043	HeartBt	077	Live Pop	111	JzBallad	<u>Traditional/Kids</u>		
009	IbizaDnc	044	HappyPop	078	GtrShfl	112	BgBndBld	145	Holiday1	
010	KeepOnDc	045	Fast Pop	<u>Oldies/Country</u>	080	Oldies	113	OrgSwing	146	Holiday2
011	90sTekno	046	'80s Bld	081	SlowRock	114	30BigBnd	147	Holiday3	
012	DjTechno	047	PopBalld	082	LoveSong	115	BigBand	148	Kids	
013	HrdTekno	048	PianoBal	083	Cool6/8	116	JazzClub	149	PopkaPop	
014	ClubHous	049	ClassBal	084	SlowDanc	117	GpsySwng	150	OrcSlFox	
015	NowHipHp	050	StoryBal	085	'60s Feel	118	UnplShfl	151	Pop Fox	
016	ElecRock	051	WayURPop	086	EarlyRck	119	JazzWltz	152	Foxtrot	
017	Rock	052	HappyBal	087	60sBeach	120	BluBogie	153	SwingFox	
018	LovlyBld	053	SimpleBl	088	MerseyBt	121	Boogie	154	Hawaiian	
019	Hip'nHop	054	MorninBl	089	50sDance	122	StrSwing	155	EngWltz	
020	Easy Hop	055	'90s Pop	090	Twistin	<u>Latin/Gospel</u>	123	AcouSmba	156	W'Waltz
021	Cool Rap	056	PoppinBl	091	60sRck'N	124	LuvBossa	157	SlWaltz	
022	PianoRap	057	SoulBlld	092	Rockin'	125	MidBossa	158	Beguine	
023	UsGroove	058	AlClapBl	093	GoGoRock	126	UpBossa	159	Rhumba	
024	Groovy P	059	LayBakBl	094	Blues	127	LatinPop	160	Charlest	
025	SunnyPop	060	UKLiteBl	095	R&B	128	UpSamba	161	Musette	
026	FeelGood	061	UpTempBl	096	Slow Old	129	BigSamba	162	Polka	
027	NightPop	062	SmilePop	097	EzCntry	130	DscSamba	163	March4/4	
028	'80s Pop	063	German P	098	CntrPop1	131	ChaCha	164	Tejano	
029	Cute Pop	064	Easy Pop	099	NewCntry	132	Mambo	165	Irish	
030	BarryDnc	065	Soul Pop	100	SlwCntry	133	Bachata	166	Ireland	
031	SteadyRk.	066	Cool Pop	101	CntryBt	134	Salsa	167	Schlager	
032	Big Rock	067	Guitar P	102	CntrPop2	135	Merengue	168	Reggae	
033	HeavyRck	068	LightBld	103	CntrSwng	136	Tango	169	Shuffle	
034	PowerRck							170	6/8March	

Music Assistant List

001 All Of Myself	062 I Walk on Line	123 Part Time Love
002 Alone Once Again	063 I Will Always Love	124 Pick Up Sax
003 Amazing the Grace	064 I will Be Surviving	125 Popcorn Synth
004 America Patrol	065 If U Know Me Now	126 Pretty Pretty Women
005 Apache Guitar	066 I'll Never Love	127 Private Dancing
006 April in France	067 I'm Standing Still	128 Pride and Mary
007 As Time Is Going By	068 Imagining	129 Put Your Hand On
008 Autumn Trees	069 In the Mood Music	130 Quando x 3
009 Ave Maria No More	070 Is She Lovely	131 Radetzky
010 Banana Boat	071 It's a small March	132 Raindrops on My Head
011 Begin to Begin	072 Jambalaya Song	133 Red River
012 Believing	073 Jealous Tango	134 Runa Way
013 Besame more	074 Jingle Bell Song	135 Sailing Song
014 Beyond the Ocean	075 Johnny B Guitar	136 Samba from Orfeu
015 Blue Blue Bossa	076 Joy to the World	137 Satin Doll Guitar
016 Blue Danube 3/4	077 Jump Rock	138 Save All my love For you
017 Blue Moonlight	078 Just The Two From Us	139 Sentimental Trip
018 Boom x 4	079 Just the Way You Are Going	140 September Disco
019 Brazil Samba	080 Just Need You Most	141 Silent of Night
020 Bridge Over Water	081 Killing Me softly with Your song	142 Singing In the Rainy Day
021 Bright Side of your life	082 LaBamba Boy	143 Smoke Gets into Your Eyes
022 Camptown Song	083 La Cumpar Tango	144 Smoke In the Water
023 Candle in Breeze	084 La Island Bonita	145 Some Thing
024 Careless Whispering	085 La Paloma Rhumba	146 Somewhere Ballad
025 Celebrating	086 Lady Nights	147 St Louis Trumpet
026 Children Trance	087 Lady in the Red	148 Stella by light
027 Copacabana	088 Last Christmas Song	149 Staying Living
028 Crazy Ballad	089 Let it be a Song	150 Stop in the Name
029 Crocodile Twist	090 Let's Twist Once Again	151 Summer Vacation
030 Dance with Queen	091 London Bridge Song	152 Sweet Georgia
031 Days Of Wine Rose	092 Love Me Softly	153 Take A Train Swing
032 Desafinado Bossa	093 Love Stories	154 Tea 4 Two
033 Desperato	094 Mack Has Knife	155 Teach Me the Nite
034 Diana 50's	095 Mambo Jumbo	156 Tenderly Jazz
035 Do-Re-Mi-Fa	096 Mas Nada Samba	157 Tequila Latin
036 Down By River	097 Memory Of Cats	158 Sound Is Silenced, The
037 Edel Waltz	098 My Mouse March	159 Tico Tico Bird
038 Fame Rock	099 Miload Swing	160 Tijuana Driving
039 Fly Me Moon	100 Mixisipi	161 Top of the World
040 Five Brothers	101 Moon River Romance	162 Unforgettable Song
041 Funky City	102 Moon Serenade	163 Uptown Lady
042 Georgia Mind	103 More Rhumba	164 Waterloo Rock
043 Give Me Give Me	104 My heart going On	165 Wave Bossa
044 Girl that's from Ipanema	105 My Own Way	166 What a Fool
045 Goodbye to Lover	106 My Life Piano	167 What a Wonderful W
046 Great Fire Balls	107 Nearness Ballad	168 When a Man Loves
047 Great Love of All	108 Never Can Say GB	169 When The Saints Going
048 Green Grass home	109 Never Sunday	March
049 Greensleaves Song	110 New York x 2	170 When Will I See U
050 Guantanamo Song	111 Nights and Days	171 When Wish A Star
051 Hard from me to Say Sorry	112 Night Is Feverish	172 White Christmas Song
052 Healing World	113 Norway Wood	173 White and Pale
053 Hey Doll	114 Sole Mio Song	174 Woman in love
054 Hello Mary	115 OHapyDay	175 YMCA Dance
055 Hero Ballad	116 Oh Lonely Me	176 You're My Life
056 House of Sun	117 Old Good Comrade	177 You Can't Hurry
057 How sensitive	118 On Sunny Side St.	178 You Needed Ballad
058 I Can Dance A Nite	119 One Note Bossa	179 Your Piano Song
059 I Get Rhythm	120 Only You Ballad	180 You Get Friend
060 I Just Say I love you	121 Over that Rainbow	
061 I Swear Ballad	122 Paloma blanca Pop	

User Program List

<u>No.</u>	<u>Name</u>	<u>Keyboard mode</u>
1	TWINPIAN	Split
2	GRANDPIA	Whole
3	EPIANO	Whole
4	HARPSICD	Whole
5	ACOUSGUI	Whole
6	STEELGUI	Whole
7	CELESTA	Whole
8	CHUORGAN	Whole
9	STRINGS	Whole
10	PIA&STRI	Layer
11	PIA&CHOI	Layer
12	EPIA&STR	Layer
13	ORGAN 8'	Whole
14	ORGAN8&4	Layer
15	CHORGBIG	Layer
16	HRPSC8&4	Layer
17	HRPSC&ST	Layer
18	CHOIR	Whole
19	HRPSC+ST	Layer
20	CHIME	Whole
21	GRANDPIA	Whole
22	BS^PIANO	Split
23	BS^VIBES	Split
24	PIA^FLUT	Split
25	PIA^FLGL	Split
26	ORG^FLUT	Split
27	ORG^OBOE	Split
28	ORG^CHIM	Split
29	SILENT	Arranger
30	NOCRYING	Arranger
31	TAKENAIR	Arranger
32	FINDBABY	Arranger
33	WALKIN'	Arranger
34	UNLINKED	Arranger