

- **World Class Multi-sampled Grand Pianos**
 - **Roland's Best RD Piano Ever**
- **The Ultimate in Expressiveness and Control**
 - **Fully Equipped for Gigging Professionals**
 - **SRX Expansion**

World Class Multi-sampled Grand Pianos

- **Features two new and different 88-note world-class concert grand pianos.**
- **Each note is multi-sampled at different velocities for supreme realism.**

Roland's Best RD Piano Ever

- **474 XV-quality tones, plus 14 rhythm kits and full GM2 engine.**
- **128-voice polyphony won't compromise notes during complex performances.**
- **Tone-wheel organ models with front panel "drawbars" and graphic display.**
- **Load and play SMF files with the new built-in MIDI File Player.**
- **125 MFX types, 6 types of Reverb, 3 types of Chorus, plus 3-Band Graphic EQ.**

The Ultimate in Expressiveness and Control

- **Roland's best top-of-the-line Progressive Hammer Action Keyboard!**
- **Built-in Arpeggiator with 126 tones, plus 185 rhythm patterns.**
- **One-touch PIANO and E.PIANO buttons recalls favorite sounds instantly.**
- **110 Setups store sounds, tone and volume settings, even Arpeggiator styles.**
- **4 control faders, large buttons and backlit display enable easy operation.**

Fully Equipped for Gigging Professional

- **1/4" and XLR outputs for balanced connection to a P.A. system.**
- **Powerful MIDI controller with assignable faders and two MIDI outputs.**
- **USB for PC/Mac MIDI control plus transfer of SMF files to MIDI File Player.**
- **Inputs for damper pedals and two-function assignable foot pedals.**

SRX Expansion

- **The RD-700SX can house two SRX expansion boards for unlimited lifespan:**
SRX-01 Dynamic Drums • SRX-02 Concert Piano • SRX-03 Studio SRX
SRX-04 Symphonic Strings • SRX-05 Supreme Dance • SRX-06 Complete Orchestra
SRX-07 Ultimate Keys • SRX-08 Platinum Trax • SRX-09 World Collection
SRX-10 Big Brass Ensemble

Play the Demo Songs

Start by playing the four demo songs in the RD-700SX:

- 1) **Hold NUM LOCK and press EDIT.**
- 2) **Use the CURSOR buttons to select a demo song.**
- 3) **Press ENTER to start playback. Press EXIT to stop playback.**

Show the Variety and Quality of Sounds

Use “One Touch” to quickly switch between acoustic and electric pianos:

- 1) **To play acoustic piano tones, press ONE TOUCH [PIANO]**
- 2) **Press [F1] to switch the type of piano.**
- 3) **Use the UP or DOWN CURSOR to adjust the height of the piano lid.**
- 4) **Press [E.PIANO] to switch to electric pianos, and [F1] to change tones.**

Use the Tone Select buttons to show some of the 488 internal tones:

- 1) **Press ONE TOUCH [PIANO] or [E. PIANO].**
- 2) **Press any of the large TONE SELECT category buttons.**
- 3) **Press [INC]/[DEC] to select different tones.**

Progressive Hammer-Action

Demonstrate Roland’s superior Hammer Action:

- 1) **Turn down the volume and examine the feel of the key bed.**
- 2) **Show the progressive weight of the keys by comparing the lowest keys (heavier) to the highest keys (lighter).**
- 3) **Compare the action of RD-700SX to other keyboards in your store.**

Sleek and Intuitive Interface

Demonstrate the Setups, Rhythms and EFX in a few easy steps:

- 1) **Press the SETUP button and use INC/DEC to choose “023 4 SPLIT”. The keyboard is divided into four different sounds: Bass, Strings, Piano and Organ.**
- 2) **Press the RHYTHM button to start the pattern.**
- 3) **Play a note in the right hand and turn the CONTROL knob under MULTI EFFECT to change the Rotary Speaker speed.**
- 4) **Press the right CURSOR to access the Drawbar screen and use the two left sliders to adjust the sound.**
- 5) **Press the right CURSOR two more times to access the Rhythm and Arpeggiator screen. Use the INC/DEC buttons to select Rhythm patterns.**
- 6) **To stop the pattern from playing, press RHYTHM until it is not lit.**