

~~EDIROL~~  
**UA-25**  
AUDIO/MIDI  
INTERFACE

---

## Welcome

Congratulations on your purchase of the Edirol UA-25. This TurboStart contains step-by-step instructions to help you get your UA-25 ready to use.

---

## Before You Connect

Before you make any connections, there are a few settings to make on the UA-25 itself.

1. Set the ADVANCED switch located on the back of the UA-25 to ON.
2. Set the SAMPLE RATE Switch to 44.1.

**Note:** Don't connect the UA-25 before installing the UA-25 driver software on your PC or Mac, as described below.

**Note:** The UA-25 supports sample rates other than 44.1 kHz. We're using 44.1 kHz here for simplicity's sake.

---

## Installing the UA-25 Driver on a Windows XP Computer

1. Turn on your computer.
2. Insert the CD-ROM that came with your UA-25.
3. When the UA-25 window opens, click "Open folder to view files," and then click OK.

**Note:** If your computer isn't set to automatically read a CD-ROM when it's inserted, you can go to the Start menu, select My Computer, and then double-click the UA-25 CD-ROM.

4. Double-click on the Driver folder.
5. Double-click on the XP2k folder.
6. Double-click on the SETUPINF file.
7. Connect the UA-25 to an open USB slot on your computer using the provided USB cable.

**Note:** After a moment or two, the Found New Hardware Wizard opens. On some computers you may get a message, "Can Windows connect to Windows update to search for software?" If you see this message, click "No, not this time," and then click "Next."

8. Select "Install from a list or specific location," and then click "Next."
9. Click "Don't search—I will choose the driver to install," and then click Next.
10. Confirm that "UA-25" shows in the models field, and then click NEXT.

# TurboStart

11. When you see, "Has not passed the Windows Logo testing," click "Continue Anyway."
12. At the Insert Disk dialog box, click OK.
13. In the Files Needed Window's "Copy files from" area, you can type in the location of the UA-25 driver, or copy and paste its file path—usually D:\Driver\XP2k—from Step 6 in the open SetupINF window.

**Note:** If the SetupINF window isn't visible behind the Files Needed Window, move the Files Needed Window out of the way so you can get to it.

14. After the Windows Logo test repeats—click "Continue Anyway" again.
15. Once the install has completed, click "Finish."
16. When the computer prompts you to restart, reboot your computer.

---

## Enabling the UA-25 for MIDI in SONAR LE

1. Open SONAR LE.
2. When you get the message, "No MIDI Outputs Selected," click "Choose MIDI Outputs Now..."
3. Click "Options" in the tool bar.
4. Enable the Edirol drivers under "Inputs" by clicking on them so they highlight in gray.
5. Enable the Edirol drivers for Outputs by clicking on them so that they turn gray.
6. Click OK to close the MIDI devices window.

**Note:** You can also get to the MIDI Devices window from the Options tab within SONAR LE.

---

## Enabling the UA-25 for Audio in SONAR LE

1. Open SONAR LE.
2. Click "Options" in the tool bar.
3. Select "Audio..." from the drop-down menu.
4. Click the Advanced tab—under "Driver Mode," select WDM/KS.
5. Click on the Drivers tab.
6. Enable the Edirol drivers under "Input Drivers" by clicking on them so that they highlight in gray.
7. Enable the Edirol drivers for Output Drivers by clicking on them so that they turn gray.
8. Click OK to close the Audio Options window.
9. You'll get a message stating that the changes will not be in effect until you restart the program. Click OK, and then restart SONAR.

~~EDIROL~~  
**UA-25**  
AUDIO/MIDI  
INTERFACE

# ***TurboStart***

---

## **Installing the UA-25 Driver on a Mac OS/X Computer**

1. Disconnect all USB cables.
2. Download the latest Mac OS X UA-25 driver from [www.Rolandus.com](http://www.Rolandus.com).
3. When the file's downloaded, double-click UA25USBDriver.tar to expand it.
4. Open the folder called "UA25USBDriver."
5. Double-click UA25USBDriver.pkg.
6. At the "Welcome to the EDIROL UA-25 USB Driver Installer" screen, click Continue.
7. When you see "Select a Destination," click the drive on which your operating system is installed, and then click Continue.
8. At Easy Install, click Install.
9. When the Authenticate dialog box appears, type in your password, and then click OK.
10. Click Continue Installation.
11. Click Restart.

---

## **Using the UA-25 to Play Audio from iTunes**

1. Use the provided USB cable to connect the UA-25 to your computer.
2. Select System Preferences... from your Apple menu, and then click Sound.
3. In the Output tab, set "Choose a device for sound output" to EDIROL UA-25 44.1 kHz.

**Note:** *The UA-25 supports sample rates other than 44.1 kHz. We're using 44.1 kHz here for simplicity's sake.*